

[Select Vehicle](#) | [New TSBs](#) | [Technician's Reference](#)

Component Search:

  [Conversion Calculator](#)**2002 Mitsubishi Eclipse GT V6-3.0L SOHC**

[Vehicle Level](#) → [Powertrain Management](#) → [Computers and Control Systems](#) → [Testing and Inspection](#)  
→ [Symptom Related Diagnostic Procedures](#) → [Inspection Procedure 8](#) ←

**Inspection Procedure 8****Unstable Idle (Rough Idle, Hunting).****COMMENT**

- In cases such as the above, the cause is probably the [air/fuel mixture](#) or idle air control motor. Other systems affecting idle quality include the [ignition system](#) and compression.


**TROUBLESHOOTING HINTS (The most likely causes for this case:)**

- Malfunction of the [ignition system](#).
- Malfunction of air/fuel ratio control system.
- Malfunction of the IAC system.
- Malfunction of the evaporative emission purge solenoid system.
- Poor compression pressure.
- Vacuum leak.
- Malfunction of the EGR solenoid system.

**DIAGNOSIS****Required Special Tool:**

- MB991502: Scan Tool (MUT-II)

**STEP 1. Check if the battery terminal is disconnected.****Q:** Has the battery terminal been disconnected lately?**YES:** Start the engine and let it run at idle for approximate **10 minutes** after engine warm up. Then, if a malfunction occurs, go to Step 2.**NO:** Go to Step 2.



Zoom

Sized for Print

## STEP 2. Using scan tool MB991502, read the diagnostic trouble code (DTC).

**CAUTION:** To prevent damage to scan tool MB991502, always turn the [ignition switch](#) to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

1. Connect scan tool MB991502 to the [data link connector](#).
2. Turn the [ignition switch](#) to the "ON" position.
3. Read the DTC.
4. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Is the DTC is output?

**YES:** Refer to Diagnostic Trouble Code Chart.

**NO:** Go to Step 3.

## STEP 3. Check the engine idling state.

**Q:** Is it hunting remarkably?

**YES:** Go to Step 4.

**NO:** Go to Step 5.

## STEP 4. Check the following items.

1. Carry out the following cleaning.
  - a. Clean the throttle valve area.
2. After cleaning, confirm that the malfunction symptom is eliminated.


**Q:** Is the malfunction symptom resolved?

**YES:** The check is completed.

**NO:** Check the following items, and repair or replace the defective items.

- a. Broken intake manifold gasket.
- b. Broken air intake hose.
- c. Broken vacuum hose.
- d. [Positive crankcase ventilation valve](#) does not operate.

Then confirm that the malfunction symptom is eliminated.



Zoom

Sized for Print

### STEP 5. Check the idle air control (IAC) motor operation sound.

1. Check that the engine coolant temperature is **20 °C (68 °F)** or below.

**NOTE:** Disconnecting the engine coolant temperature sensor connector and connecting the harness side of the connector to another engine coolant temperature sensor that is at **20 °C (68 °F)** or below is also okay.


2. Check the operation sound of the IAC motor can be heard after the ignition is switched to the "ON" position (but without starting the engine).
  - An operation sound is heard.
3. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Did you hear the operation sound?

**YES:** Go to Step 6.

**NO:** Refer to DTC P0506 - Idle Control System RPM Lower Than Expected, DTC P0507 - Idle Control System RPM Higher Than Expected.





Zoom

Sized for Print

**STEP 6. Using scan tool MB991502, check actuator test items 01, 02, 03, 04, 05, 06: Injector.**


**CAUTION:** To prevent damage to scan tool MB991502, always turn the [ignition switch](#) to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

1. Connect scan tool MB991502 to the [data link connector](#).
2. Turn the [ignition switch](#) to the "ON" position.
3. Check following items in the actuator test. Refer to Actuator Test Reference Table.
  - a. Item 01, 02, 03, 04, 05, 06: Injector.
4. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Is the actuator operating properly?

**YES:** Go to Step 7.

**NO:** Refer to DTC P0201, P0203, P0205 - Injector Circuit, DTC P0202, P0204, P0206 - Injector Circuit.




Zoom

Sized for Print

**STEP 7. Using scan tool MB991502, check data list.**

1. Turn the [ignition switch](#) to the "ON" position.
2. Check the following items in the data list. Refer to Data List Reference Table .
  - a. Item 13: [Intake Air Temperature Sensor](#).
  - b. Item 25: Barometric Pressure Sensor.
  - c. Item 21: Engine Coolant Temperature Sensor.
  - d. Item 69: Right Bank Heated Oxygen Sensor (rear).
  - e. Item 39: Right Bank Heated Oxygen Sensor (front).
  - f. Item 59: Left Bank Heated Oxygen Sensor (rear).
  - g. Item 11: Left Bank Heated Oxygen Sensor (front).
  - h. Item 27: [Power Steering Pressure Switch](#).
  - i. Item 28: A/C Switch.
3. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Are they operating properly?**YES:** Go to Step 8.**NO:** Repair or replace. Then confirm that the malfunction symptom is eliminated.

Zoom

Sized for Print

**STEP 8. Using scan tool MB991502, check actuator test.**


1. Turn the [ignition switch](#) to the "ON" position.
2. Check the following items in the actuator test. Refer to Actuator Test Reference Table.
  - a. Item 08: Evaporative Emission Purge Solenoid.
  - b. Item 10: EGR Solenoid.

3. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Are they operating properly?

**YES:** Go to Step 9.

**NO:** Repair or replace. Then confirm that the malfunction symptom is eliminated.



Zoom

Sized for Print

**STEP 9. Using scan tool MB991502, check data list.**


1. Turn the [ignition switch](#) to the "ON" position.
2. Check the following items in the data list. Refer to Data List Reference Table.
  - a. Item 45: Idle Air Control Motor Position.
3. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Is the actuator operating properly?

**YES:** Go to Step 10.

**NO:** Adjust the basic [idle speed](#). Refer to Basic Idle Speed Adjustment. After adjusting, confirm.





Zoom

Sized for Print

### STEP 10. Using scan tool MB991502, check data list.

1. Turn the [ignition switch](#) to the "ON" position.
2. Check the following items of the data list. Refer to Data List Reference Table.
  - a. Item 39: Right Bank Heated Oxygen Sensor (front).
  - b. Item 11: Left Bank Heated Oxygen Sensor (front).
    - Voltage should fluctuate between **0 - 0.4 volts** and **0.6 - 1.0 volts** while idling after the engine has been warmed.
3. Turn the [ignition switch](#) to the "LOCK" (OFF) position.

**Q:** Is the sensor operating properly?

**YES:** Go to Step 12.

**NO:** Go to Step 11.

**STEP 11. Check the [fuel pressure](#).**  
Refer to Fuel Pressure Test.

**Q:** Is the [fuel pressure](#) normal?

**YES:**

- a. Check the following items, and repair or replace the defective items.
  - Vacuum leak.
  - Broken intake manifold gasket.
  - Broken air intake hose.
  - Broken vacuum hose.
  - [Positive crankcase ventilation valve](#) does not operate.

- b. Injector clogged.

Then confirm that the malfunction symptom is eliminated.

**NO:** Repair or replace. Then confirm that the malfunction symptom is eliminated.

**STEP 12. Check the [ignition timing](#).**

Refer to On-vehicle Service - Ignition Timing Check.

**Q:** Is the [ignition timing](#) normal?

**YES:** Check the following items, and repair or replace the defective items.

- a. Check the [ignition coil](#), [spark plugs](#), spark plug cables.
- b. Check the purge control system.
- c. Check compression pressure.
- d. Check if the foreign materials (water, kerosene, etc.) got into fuel.
- e. Check the [EGR](#) control system.

Then confirm that the malfunction symptom is eliminated.

**NO:** Check that the [crankshaft position sensor](#) and timing belt cover are in the correct position. Then confirm that the malfunction symptom is eliminated.