


1999 Jeep Truck Wrangler L4-2.5L VIN P

[Vehicle Level](#) → [Transmission and Drivetrain](#) → [Differential Assembly](#) → [Seals and Gaskets](#) → [Service and Repair](#) → [Pinion Seal, Rear Differential](#) → [With 194 RBI Axle](#) ←

With 194 RBI Axle[Notes](#)**REMOVAL**

1. Raise and support the vehicle.
2. Remove wheel and tire assemblies.
3. Remove the brake drums. Refer to Brakes and Traction Control, for proper procedures.
4. Mark the propeller shaft and pinion yoke for installation alignment reference.
5. Remove the propeller shaft from the yoke.
6. Rotate the [pinion gear](#) three or four times.
7. Measure the amount of torque necessary to rotate the [pinion gear](#) with a (inch lbs.) dial-type torque wrench. Record the torque reading for installation reference.
8. Using Holder 6958 to hold the pinion yoke, remove the pinion nut and washer.




Zoom

Sized for Print

9. Use Remover C-452 and Wrench C-3281 to remove the pinion yoke.

10. Use a suitable pry tool or slide hammer mounted screw to remove the [pinion gear seal](#).


INSTALLATION



Zoom

Sized for Print

1. Apply a light coating of [gear](#) lubricant on the lip of pinion seal. Install seal with Installer C-3972-A and Handle C-4171.




Zoom

Sized for Print

2. Install yoke on the [pinion gear](#) with Screw 8112, Cup 8109, and Holder 6958.

CAUTION: Do not exceed the minimum tightening torque when installing the pinion yoke at this point. Damage to the collapsible spacer or bearings may result.


3. Install the yoke washer and a new nut on the [pinion gear](#) and tighten the pinion nut until there is zero bearing end-play.
4. Tighten the nut to **271 Nm (200 ft. lbs.)** . **CAUTION:** Never loosen [pinion gear](#) nut to decrease pinion gear bearing rotating torque and never exceed specified preload torque. If preload torque or rotating torque is exceeded a new collapsible spacer must be installed. The torque sequence will then have to be repeated.




Zoom

Sized for Print

5. Rotate the pinion shaft using a (inch lbs.) torque wrench. Rotating torque should be equal to the reading recorded during removal plus an additional **0.56 Nm (5 inch lbs.)** .



[Zoom](#)[Sized for Print](#)

6. If the rotating torque is low, use Holder 6958 to hold the pinion yoke, and tighten the pinion shaft nut in **6.8 Nm (5 ft. lbs.)** increments until the proper rotating torque is achieved. **CAUTION:** If the maximum tightening torque is reached prior to reaching the required rotating torque, the collapsible spacer may have been damaged. Replace the collapsible spacer.
7. Align the installation reference marks on the propeller shaft and yoke and install the propeller shaft.
8. Add [gear](#) lubricant to the differential housing, if necessary. Refer to the Lubricant Specifications for gear lubricant requirements.
9. Install the brake drums.
10. Install wheel and tire assemblies.
11. Lower the vehicle.

© 2010 ALLDATA LLC. All rights reserved.

[Terms of Use](#)