

2001 Ford Windstar

2000-01 BRAKES Anti-Lock/Traction Control - Windstar

DIAGNOSTIC TROUBLE CODE DEFINITIONS

DTC	Description	Action/Go To Test
B1317	Battery Voltage High	<u>C</u>
B1318	Battery Voltage Low	<u>C</u>
B1342	ECU Is Defective	Replace ABCM
B2477	Module Configuration Failure	(1)
C1095	Hydraulic Pump Motor Circuit Failure	<u>D</u>
C1096	Hydraulic Pump Motor Circuit Open	<u>D</u>
C1103	Hydraulic Brake Pressure Switch Circuit Failure (2000)	<u>E</u>
C1103	Hydraulic Brake Pressure Switch Circuit Failure (2001)	<u>E</u>
C1115	Power Relay Output Short To Power	<u>F</u>
C1145	RF ABS Sensor Input Circuit Failure	<u>G</u>
C1155	LF ABS Sensor Input Circuit Failure	<u>G</u>
C1165	RR ABS Sensor Input Circuit Failure	<u>G</u>
C1169 (2)	Excess Dump Time	<u>L</u>
C1175	LR ABS Sensor Input Circuit Failure	<u>G</u>
C1184	ABS System Timeout (2000)	<u>H</u>
C1184	ABS System Timeout (2001)	<u>H</u>
C1185	Power Relay Output Circuit Failure	<u>F</u>
C1194	LF Dump Valve Circuit Failure	<u>I</u>
C1198	LF ISO Valve Circuit Failure	<u>I</u>
C1210	RF Dump Valve Circuit Failure	<u>I</u>
C1214	RF ISO Valve Circuit Failure	<u>I</u>
C1222 (2)	Wheel Speed Error (Mismatch)	<u>J</u>
C1233	No LF ABS Sensor Signal (2000)	<u>J</u>
C1233	No LF ABS Sensor Signal (2001)	<u>J</u>
C1234	No RF ABS Sensor Signal (2000)	<u>J</u>
C1234	No RF ABS Sensor Signal (2001)	<u>J</u>
C1235	No RR ABS Sensor Signal (2000)	<u>J</u>
C1235	No RR ABS Sensor Signal (2001)	<u>J</u>
C1236	No LR ABS Sensor Signal (2000)	<u>J</u>
C1236	No LR ABS Sensor Signal (2001)	<u>J</u>
C1242	LR Dump Valve Circuit Failure	<u>I</u>
C1246	RR Dump Valve Circuit Failure	<u>I</u>
C1250	LR ISO Valve Circuit Failure	<u>I</u>
C1254	RR ISO Valve Circuit Failure	<u>I</u>
C1404	RF Traction Control Valve Circuit Failure	Replace ABCM
C1410	LF Traction Control Valve Circuit Failure	Replace ABCM

2001 Ford Windstar

2000-01 BRAKES Anti-Lock/Traction Control - Windstar

C1446	Brake Pedal Position Failure	(3)
U1009	Invalid Or Missing Engine Torque Data	Perform Self-Test
U1027	Invalid Or Missing Engine RPM Data	Perform Self-Test
U1059	Invalid Or Missing Transmission/Gear Position Data	Perform Self-Test
U1262 (2)	SCP Bus Missing	Perform Self-Test

(1) See SELF-DIAGNOSTICS - EEC-V article in ENGINE PERFORMANCE.

(2) DTC applies to 2001 models only.

(3) See appropriate DISC & DRUM article.