


1991 Toyota Corolla Sedan L4-1587cc 1.6L DOHC (4A-GE)

Vehicle Level → Heating and Air Conditioning → Blower Motor Switch → Service and Repair ←

Service and Repair

[Notes](#)


**BLOWER SPEED CONTROL SWITCH INSPECTION**



Zoom

Sized for Print

1. REMOVE BLOWER SPEED CONTROL SWITCH
  - (a) Remove the illumination light from the A/C control assembly.




Zoom

Sized for Print

- (b) Using a screwdriver, pry loose the clip and push out the blower speed control switch to rear of the A/C control assembly.

Testing Blower Motor Switch



Zoom

Sized for Print

2. INSPECT BLOWER SPEED CONTROL SWITCH CONTINUITY If continuity is not as specified. replace the blower speed control switch.

© 2010 ALLDATA LLC. All rights reserved.

[Terms of Use](#)