


2007 Honda Truck Ridgeline V6-3.5LVehicle Level → [Lighting and Horns](#) → [Headlamp Bulb](#) → [Service and Repair](#) ←**Service and Repair**[Notes](#)**Bulb Replacement****Headlight**

Zoom

Sized for Print

1. Disconnect the 3P connector (A) from the headlight.
2. Turn the bulb socket (B) 45 "counterclockwise to remove the bulb.
3. Install a new bulb in the reverse order of removal.