Front Bumper

Removal and Installation

All Vehicles

1. Raise the vehicle. For additional information, refer to Section 100-01.

2. Position aside the air deflector.
   1. Remove the forward pin-type retainers.
   2. Position the air deflector rearward.



Vehicle equipped with fog lights

3. **NOTE:** Left side shown, right side similar.

   Disconnect the electrical connector.



4. Position aside the wiring harness.

All vehicles

5. **NOTE:** Left side shown, right side similar.

   Remove the front bumper (17757).
   1. Remove the four bolts.
   2. Remove the bumper.



Vehicle requiring a new front bumper

6. Transfer all undamaged parts to the new front bumper.

All vehicles

7. To install, reverse the removal procedure.